

INSTALLATION INSTRUCTIONS FOR COLLAR HANDLE ON 4" SS MAINSTAY PEDESTAL

To prevent damage during shipping stainless steel Mainstay pedestals are shipped without the locking collar handle installed.

To install the handle simply screw the threaded end into the locking collar starting from the non-threaded counterbored side as shown.

This handle should remain loose while adjusting the vertical height of the pedestal. Once the pedestal is at the desired height the collar handle should be tightened to remove any wobble or rotational play between the inner and outer posts.

