

# INSTALLATION INSTRUCTIONS FOR TRACK-LOCK 3 CABLE OPERATED SLIDES

The Cable Operated Slide system furnished by Springfield Marine Company is designed to mount to your seat in several different configurations. Because of this there are a few adjustment procedures that may be required during installation. **WARNING!** Failure to follow these procedures may result in the swivel lock pin not properly locking the swivel in place, which could result in injury or death.

1. The slide must be mounted in such a way that the cables do not contain any sharp bends, kinks, or tight loops.
2. The Cable Activation Controls must be securely mounted to a stable surface on the seat.
3. Once the slide assembly is installed onto the seat bottom both the slide and swivel activation cables may require adjustment. To do so see the instructions below:
  - a) Verify that the Slide Latch (01) is flush or below the Swivel Lock Teeth (02). If not loosen the jam nut (03) and turn the Slide Adjustment Nut (04) towards the slide end cap until properly adjusted.
  - b) Use the provided gauge (See fig. 1) to verify that the Swivel Lock Pin (05) is protruding into the swivel cup to the proper depth. The end of the pin must be flush with the face of the gauge or slightly beyond the gauge face towards the swivel cup center. If not loosen the jam nut (06) and turn the Swivel Adjustment Nut (07) away from the swivel until properly adjusted.

