

# ASSEMBLY INSTRUCTIONS FOR DELUXE CHAIR STAND

1. Install the Heavy Duty Swivel Mount (Item# 1) to the bottom of your seat\*. \*Due to variances in seat substrates mounting hardware to mount the Heavy Duty Swivel Mount to your seat is not included. Contact your seat manufacturer or dealer for recommended hardware type. A #12 screw is the smallest diameter recommended.
2. Place the Upper Leg (Item# 3) over the Lower Leg (Item# 4) as shown. Place one of the 5 short bolts (Item# 2) provided through the legs. Place a Ny-Lock Nut (Item# 6) onto the bolt . Do not tighten at this time.
3. Place the Foot Rest Rail (Item# 7) over the legs and align the mounting holes.
4. Place the four provided long bolts (Item#5) through the Foot Rest Rail and the legs. Place a Ny-Lock Nut (Item# 6) onto the bolt and securely tighten each bolt.
5. Tighten the short bolt that was installed during step #2.
6. Rotate the Heavy Duty Swivel Mount (Item# 1) that was installed on to your seat during step #1 so that there is access to the remaining mounting slots. Use the remaining short bolts (Item# 2), and Ny-Lock Nuts (Item# 6) to securely mount your seat to the assembled Deluxe Chair Stand.

Note: Your Deluxe Chair Stand does not fasten to your boat deck and should not be occupied above 5 miles per hour. Serious injury or death may result.

